



PCG

PIONEER CONTROL GRIPS

MOUNTING GUIDANCE

- DRILL A 5/16" HOLE APPROXIMATELY 4" DOWN FROM TOP OF CONTROL STICK FOR WIRE ROUTING.
- MOUNTING HOLE IS A CLOSE TOLERANCE FIT. IF GRIP DOES NOT EASILY GO ON, REMOVE COATING FROM LAST 3" OF CONTROL STICK AND SMOOTH.
- POSITION THE GRIP FOR BEST COMFORT AND TIGHTEN SET SCREW ON THE LOWER, FORWARD FACE OF THE GRIP.

TERMINATION GUIDANCE

- ALL SWITCHES ARE MOMENTARY, N.O. SHARING A COMMON GROUND.
- TOGGLE SWITCH WIRING IS AN ADDED OPTION. CAP AND STOW WHEN NOT IN USE.
- CAP AND STOW SPARE LIGHT BROWN WIRE

WE'RE HERE TO HELP! ANY ADDITIONAL QUESTIONS CAN BE SENT THROUGH OUR WEBSITE (WWW.PIONEERCONTROLGRIPS.COM) OR EMAIL (PIONEERCONTROLGRIPS@GMAIL.COM)

